



Safe Communications in Dermatology Offices

How do you provide a safe environment for staff and patients while enabling communication across a safety shield?



How it Works

A speaker and microphone are installed on the front of the shield on the patient side and on the side of the office staff. In addition, full audio controls are installed on the staff side which can vary the volume output to both speakers and the input to both microphones. In this manner the sound levels can be optimized for the environment. The shield should cover the entire space between patient and staff member to maximize protection.

For those with hearing loss a hearing loop broadcasts an induction loop signal directly to the T Coil equipped hearing aid or cochlear implant thus enabling clear and confidential discussions to take place for complete ADA and HIPAA compliance.



Locations for 2-Way Talker Shield

- Admitting Specialty Department Registration
- Medical Office Consult & Checkout

Benefits

- Improved communication between staff and patients/visitors including those with hearing loss
- Peace of mind for both patients and staff
- Increased volume of patient visits
- Complies with CDC Guidance for providing a barrier to help prevent spreading of infections from viruses and other airborne diseases without having to wear a mask or respirator
- ADA compliance for accommodating those who depend upon hearing aids and cochlear implants



Audio Directions
www.AD4H.com

peggy@AD4H.com
(Southern States)

1-833-234-4411

sally@AD4H.com
(Northern States)